

USER MANUAL - BATTERY PACK UNIT

- Charging Battery Pack in "Gridmode"

1. Shut down the refrigerator by switching the "On/Off" switch to "Öff".
2. Connect the Grid plug to the Grid connection.
Unit will start automatically after approx. 10 seconds delay.
3. Start-up takes approx. 60 seconds. Start-up cycle is shown in display.
Unit is operational when **"ON Gridmode"** is visible in display.



On/Off switch refrigerator

- Stop (power-down) of Battery Pack in "Gridmode"

1. Remove Grid plug from the Grid connection.
2. Press "STOP" to power-down the unit.
3. When display is off (black) the battery pack is switched off.

- Use of Battery Pack in "Roadmode"

1. Press "START" to activate Battery Pack.
2. Start-up takes approx. 60 sec. Start-up cycle is shown in display.
Unit is operational when **"ON Roadmode"** is visible in display.



- Stop (power-down) of Battery Pack in "Roadmode"

1. Shut down the refrigerator by switching the "On/Off" switch to "Öff".
2. Press "STOP" to power-down the unit.
3. When display is off (black) the battery pack is switched off.

- Emergency Stop or total shut-down of Battery Pack

1. In case of emergency or total shut-down press the "EMERGENCY STOP" button on the side of the remote control box.
2. In case of an "ERROR" or "WARNING" press the "EMERGENCY STOP" button on the side of the remote control box.
Wait 5 minutes and release the "EMERGENCY STOP" button by twisting it clock-wise and restart the unit.



- Technical support

If a fail appears, try to shut down the unit using the "EMERGENCY STOP" button on the side of the remote control box. When the fail keeps reappearing, please contact TRS at phone number +31714050070.